

RIEE 32581476  
32581490

# Assembly instructions for Nightstand

146 / 147 / 148-150 & 8147 / 8149-150


PAGE 1 OF 1

**Caution:** Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

- Do not allow children to climb on furniture.
- Do not place television sets on top of chests, door chests and/or dressers.
- Please place heaviest objects in the lowest drawers.
- Please have no more than one drawer open at a time.

Hardware List for NightStand (146 / 147 / 148-150 & 8147 / 8149-150)			
1		Allen Key (3-1/8")	1 piece
2		Bolt (Φ5/16*3")	4 pieces
		Spring Washer (Φ5/16")	4 pieces
		Flat Washer (Φ5/16")	4 pieces

No.	Parts List		
A		Bun feet	4 pcs

