

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staple used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts until the assembly is complete
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LISTS

| NO | IMAGE                                                                             | ITEM DESCRIPTION | Q' TY |
|----|-----------------------------------------------------------------------------------|------------------|-------|
| 1  |  | SIDEBORD         | 1 PC  |


HARDWARE LISTS

| NO | IMAGE                                                                             | ITEM DESCRIPTION            | Q' TY |
|----|-----------------------------------------------------------------------------------|-----------------------------|-------|
| A  |  | FURNITURE TIPPING RESTRAINT | 1 SET |

STEP 1



Anti-Tip Hardware-  
customer assembly required





Not included

Remark: There is a tip restraint kit provided on the back of this product. Please read the directions thoroughly and install immediately when placed in home.

STEP 2

OPTION 1 : For wine rack shelf purpose

There is the power with USB type A-C on the left side panel of Sideboard





Not included

If you refer to adjust the shelf location, remove the screws and move shelf brackets to the desired location. Then secure the brackets to shelf with screws.

STEP 3

OPTION 2 : For flat shelf purpose

There is the power with USB type A-C on the left side panel of Sideboard




Not included

If you refer to adjust the shelf location, remove the screws and move shelf brackets to the desired location. Then secure the brackets to shelf with screws.

Hardware pack locations:

9153 -9 SIDEBORD W/ POWER UNIT  
SKU: 42991530

**STEP 4**  
**COMPLETE**



# IMPORTANT SAFETY INSTRUCTIONS



## WARNING

Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK

**ELECTRIC RATING (125V / 12A / 1500W)  
POWER TECHNOLOGY TRADING MANUFACTURE CO., LTD  
PART NUMBER (PW-A2011A-PD)**

**Read all instruction before using this furnishing.**

**DANGER - To reduce the risk of electric shock:**

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

**WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:**

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.

# INSTRUCCIONES DE SEGURIDAD IMPORANTES



## WARNING

El mal puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

**CLASIFICACION ELECTTRICA (125V / 12A / 1500W)  
POWER TECHNOLOGY TRADING MANUFACTURE CO., LTD  
NUMERO DE CATALOGO DE LA INSTALACION DEL CABLE  
DE ALIMENTA-CION (PW-A2011A-PD)**

**Leer todas las instrucciones antes de usar este mobiliario**

**PELIGRO - Para reducir el riesgo de descarga electrica:**

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

**ADVERTENCIA : para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:**

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.