## **ASSEMBLY INSTRUCTION**

## ITEM:Metal/Wood-End Table

	HEM:Metal/Wood-End Table						
NO	PART LIST	QTY		Begin assembly by attaching metal wire legs (2) to the bottom side of the top tray(1) and screwing	STEP 2	Attach the bottom side of the second tray (1) and screwing 2pcs screws (A)each leg using screw	
1)	TRAY	2PCS		2pcs screws(A) each leg using screw driver.		driver.	
2	METAL WIRE LEGS	3PCS	STEP 3	Assembly Complete.			
NO	HARDWARE LIST	QTY					
A	FLAT HEAD SCREWS Ø3 x10 mm	12PCS					