Progressive® furniture

ASSEMBLY INSTRUCTION

T360-71 DESK/VANITY

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Indentify and count all parts and compare with the Hardware List as below:

