

111-1N (32134114) Triple Dresser 111-2 (32231110) Mirror Assembly Instructions

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

**Assemble the product on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Read all instruction and

study the drawings carefully before starting the assembly process.

			Hard	lware packed	l in Dresser		TOOLS REQUIRED (NOT PROVIDED)
NO. SKETCH	DESCRIPTION	Q'TY		SKETCH	HARDWARE	Q'TY	PHILLIPS SCREWDRIVER —
101 51151611	B B B B T T T T T T T T T T T T T T T T		a	0	Φ1/4"x20x2"	8 pcs	THILLII 3 SCREWBRIVER
	D	100	b	0	Φ1/4"	8 pcs	
A	Dresser	1pc	С	0	Φ1/4"x19mm	8 pcs	
			d		4mm	1 pc	
В	Mirror	1pc	е	9	Furniture tipping restraint	1 set	
C ====	Support mirror	2pcs		ware packed	d in Mirror		
D 🗀	Back feet (L/R)	2pcs		SKETCH	HARDWARE	Q'TY	c
E 🕥	Front feet	2pcs	f		Φ1/4"x20x1-1/2"	8 pcs	b
F S	Support leg	1pc	g h	0	Φ1/4" Φ1/4"x19mm	8 pcs 8 pcs	a
Step 2 Remove all Wooden blocks rom the bottom of the case viece before ssembling.	Step 1 Wooden block	et box		Step 5	WALL	ÿ f	d MADE IN VIETNAM