








Assembly Instructions for




NAJA BDCAPDR 32175627 7562-DR DRESSER GRAY WHITE
 NAJA BDCAPMR 32275629 7562-MR MIRROR GRAY WHITE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the HARDWARE LIST below.

Caution : Please read instructions thoroughly before unpacking assembly parts.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.
3. Please put all parts on a non - abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

NO.	Hardware List	Q'TY
1	 Flat washer: Ø5/16"*Ø23*2mm	8
	 Spring washer: Ø5/16"*Ø13*2mm	
	 Allen bolt: Ø5/16"*13*35mm	
1	 Allen wrench: 4mm	1
	 Tipping restraint	1

NO.	Part List	QTY
A	 Dresser	1
B	 Mirror	1
C	 Mirror brackets	2

