



**PARTS LIST**

Sym-bol	Description	Sketch	Qty
A	Chair		1
B	Brace		1
C	Washer - M6 X 16		4
D	SPRING WASHER M6		4
E	Bolt - M6 X 20		4
F	Allen Key - 4MM		1

\*\*\*Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are highly recommended for the assembling process in order to prevent personal injury and ensure the parts are not damaged during the assembly.

**STEP 1:** Install Brace (B) onto Chair (A) using the 4x Washer - M6 X 16 (C), 4x SPRING WASHER M6 (D) & 4x Bolt - M6 X 20 (E) with Allen Key - 4MM (F) but don't fully tighten bolts. Please make sure all bolts can be screwed in smoothly and not cross threaded then fully tighten all bolts.

