## **ASSEMBLY INSTRUCTIONS ITEM NO:** 95460/95461/95462/95463

Thank you for purchsing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten).

screws/bolts first. Once the item is assembled then completety tighten).								
PART LIST:					HARDWA			
NO:	DESCRIPPTION	SKETCH	QUALITY	NO:	SKETCH	DESCRIPPTION	SIZE	QUALITY
1	Back Chair	Ш	1Pc	Α	<i>amma</i>	Allen Head Bolt	Ø8x90mm	4 Pcs
			•	В	(a) minimini	Allen Head Bolt	Ø8x55mm	4 Pcs
2	Seat		1Pc	С	(i)	Allen Head Bolt	Ø8x45mm	2 Pcs
				D	<u> </u>	Allen Head Bolt	Ø6x40mm	2 Pcs
3	Left Front Leg	Left	1Pc	Е	<b>6</b>	Lock Washer	Ø8xØ13	12 Pcs
4	Right Front Leg	Rgfi	1Pc	F	0	Flat Washer	Ø8xØ20	10 Pcs
				G	0	Flat Washer	Ø6xØ13	2 Pcs
5	Backrest pillow and seat cushion		2Pcs	Н		Allen Key	Ø5x110mm	1 Pc
				I		Cover Cap	Ø14.2x7mm	2 Pcs
(H) (E) (C) (H) (2)								
STEF	(H)(B)	(E) (F)	(F	(5) Finish:				

MADE IN VIETNAM

PAGE 1 OF 1