

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 22545

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Carefully unpack all lamp parts from carton. We suggest a licensed electrician for all fixture installations.

1. Take the lamp carefully out of the Carton, and place on a flat surface.
2. Be sure power to the installation point is OFF.
3. Pull the power supply wire out from the outlet box and mount the **Cross Bar** to the outlet box with Outlet Box Screws.
4. Connect the wire as shown.
 - a. Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.
 - b. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.
 - c. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut.
 - d. Carefully stuff all of the connected wires into the Outlet Box.
5. Attach **Fixture Body** over the **Nipple** and secure again by threading **Knob** onto end of **Nipple**. Tighten until snug.
6. Install the correct Bulb (Not Included) into the Socket until snug.
7. Place the **Fabric Shade** carefully onto the **Stem** and thread the **Finial** and **Plastic Washer** into **Stem** to secure it..
8. This wall sconce total have 2 pieces, one left and one right. Assembly steps are same.

Your installation is completed now. Restore electricity.

