



UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# 22274

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Be sure the power to the installation point is power off.
3. Place the Mica Diffuser, Rubber Washer onto the Shade.
Thread the Metal ball with nipple to tighten.
4. Place the Universal Bar over the Ceiling Canopy and thread Mounting Ball onto the Mounting Screw to secure it. Hand tighten until snug.
5. Twist the proper wattage bulb. (Not Included)

Your installation is completed now. Restore electricity.
Retain this sheet for future reference !

