



Manufactured for Rooms To Go

ASSEMBLY INSTRUCTIONS

Vendor code : FFLA


MODEL : F4014SS K (3S)

SKU#10141454,10141466,10141478,10141480

Thanks you for purchasing this quality product. Be sure to lay all components on a soft and clean surface before assembly in order to avoid components from being scratched.

CAUTIONS :

1. Check contents against list for quantity.
2. Familiarize yourself with the components and hardware by reviewing the Assembly Instructions.
3. Do not over tightened the screws and bolts as it may damage the threads.
4. Keep all hardware parts out of the reach of children.
5. Please "LIFT UP & MOVE" the sofa when ever you want to shift it.




COMPLETED ASSEMBLY


PARTS LIST			HARDWARE LIST		
NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
1	ARM	2 PCS	A	M6 X 25MM JCBC SCREW	5 PCS
2	BACK RAIL	1 PC	B	L- BRACKET (1 HOLE)	2 PCS
3	FRONT RAIL	1 PC	C	LEG	4 PCS
4	BACKREST	1 PC	D	M4 ALLEN KEY	1 PC
5	SEAT	1 PC	E	SUPPORT LEG	1 PC
6	BACK CUSHION	2 PCS			

* PLEASE UNTIE THE STRING FROM THE ARM CONNECTOR FOR 'SOFA LEGS' HARDWARE IN RED PLASTIC BAG BEFORE LIFTING UP THE ARM.


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

