

**TOOLS REQUIRED:NO TOOLS REQUIRED**


**PART LIST**

| NO. | DESCRIPTION   |   | Q'TY |
|-----|---------------|---|------|
| A   | LOVESEAT      |  | 1PC  |
| B   | LEGS          |  | 4PCS |
| C   | BACK CUSHIONS |  | 2PCS |
| D   | PILLOWS       |  | 2PCS |

**HARDWARE LIST**


|   |  |   |      |
|---|--|---|------|
| 1 | BOLT (5/16x18x45 <sup>m</sup> / <sub>m</sub> )           |  | 8PCS |
|   | SPRING WASHER (5/16x13x1.5 <sup>m</sup> / <sub>m</sub> ) |   |      |
|   | FLAT WASHER (5/16x19x2 <sup>m</sup> / <sub>m</sub> )     |   |      |
| 2 | ALLEN KEY (4 <sup>m</sup> / <sub>m</sub> x32 x75)        |  | 1PC  |

**STEP 1:**




Hardware Pack + Legs inside


**STEP 2:**



**STEP 3:**



**Completed**



# Caring for Your Furniture

To ensure your loveseat maintains its beauty, comfort, and durability for years to come, please follow these Care & Maintenance Guidelines.

## The Enemies of Furniture

To extend the life of your loveseat, avoid exposure to these common threats:

- **Sunlight & Heat:** Direct sunlight or heat sources may cause fading, discoloration, or fabric deterioration.
- **Moisture:** Wipe up spills immediately and avoid placing the loveseat in damp or humid areas. Excess moisture may damage both the fabric and the wooden legs.
- **Harsh Chemicals:** Do not use bleach, ammonia, or solvent-based cleaners. Use only mild soap and water when necessary.
- **Sharp Objects:** Keep keys, tools, and other sharp items away from the upholstery to prevent snags or tears.
- **Uneven Surfaces:** Place the loveseat on an even floor to prevent stress on the wooden frame and legs.

## Tips for Better Maintenance

Simple care routines will keep your loveseat looking and feeling its best:

- **Weekly Dusting:** Vacuum the fabric using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** Blot (do not rub) minor stains with a mild soap solution and a clean damp cloth. Allow to air dry fully.
- **Cushion Care:** Fluff and rotate cushions regularly to maintain their shape and comfort.
- **Wood Care:** Wipe wooden legs with a soft, dry cloth. Avoid standing water or wet mopping around the base.
- **Hardware Check:** Periodically inspect and tighten any bolts or connectors to maintain stability.

With proper care, your loveseat will remain stylish, comfortable, and supportive for years to come.

☞ For indoor residential use only.

140



# Assembly Instructions

25002C-1 CHAIR SKU#10395045    25002L-1 LOVESEAT SKU#10295043    25002S-1 SOFA SKU#10195041  
25002C-2 CHAIR SKU#10395021    25002L-2 LOVESEAT SKU#10295029    25002S-2 SOFA SKU#10195027  
25002C-3 CHAIR SKU#10395019    25002L-3 LOVESEAT SKU#10295017    25002S-3 SOFA SKU#10195015

This product is manufactured by GINA for ROOMS TO GO ►

## HARDWARE LIST

|   |  |   |      |
|---|--|---|------|
| 1 | BOLT (5/16x18x45 <sup>m</sup> / <sub>m</sub> )           |    | 8PCS |
|   | SPRING WASHER (5/16x13x1.5 <sup>m</sup> / <sub>m</sub> ) |   |      |
|   | FLAT WASHER (5/16x19x2 <sup>m</sup> / <sub>m</sub> )     |   |      |
| 2 | ALLEN KEY (4 <sup>m</sup> / <sub>m</sub> x32 x75)        |  | 1PC  |



**1** BOLT (5/16x18x45<sup>m</sup>/<sub>m</sub>)=8pcs

**2** Allen key (4<sup>m</sup>/<sub>m</sub>x32x75)=1pc

Nền trắng (White background)

160