


# Fusion Furniture, Inc. - Leg Assembly Instructions

**How to install Legs:**

1. Remove the bubble wrap from the each leg and remove the cap from the screw on the top of the leg.
2. Place round spacer disk around screw, if included.
3. Locate the hole in the corner of black material on the bottom of the sofa.
4. Insert the screw end of one leg into the hole and turn clock-wise.
5. Continue turning until the leg is snug and secure. **\*Do not over tighten!\***
6. Repeat steps 3-4 for all four corners. Most styles only require 4 legs, but if there are 5 legs in the bag, place the 5th leg in the center of front rail (as shown below).


**Comment installer les jambes:**

1. Retirez l'enveloppe à bulle de chaque jambe et retirez le capuchon de la vis sur le dessus de la jambe
2. Placez le disque circulaire autour de la vis, si inclus
3. Localisez le trou dans le coin du matériau noir sur le fond du canapé
4. Insérez l'extrémité de la vis d'une jambe dans le trou et tournez-vous dans le sens des aiguilles d'une montre
5. Continuez à tourner jusqu'à ce que la jambe soit bien serrée et sécurisée. **\*Ne pas trop serrer!\***
6. Répétez les étapes 3 à 4 pour les quatre coins. La plupart des styles ne nécessitent que 4 jambes, mais s'il y a 5 jambes dans le sac, placez la 5ème jambe au centre du rail avant (comme indiqué ci-dessous).



Back

5<sup>th</sup> Leg (if included)



L'arrière

5<sup>th</sup> Leg (si inclus)

**\*\*the above insert is included with all leg packages in product\*\***

RTG Product SKU	Fusion SKU	RTG Product SKU	Fusion SKU
10130158	3003-00-RTG	10430166	702-RTG
10130160	3003-00-RTG	10430457	702-RTG
10130451	3003-00-RTG	10530156	3003-02-RTG
10130639	3003-00-RTG	10530168	3003-02-RTG
10230150	3003-01-RTG	10530459	3003-02-RTG
10230162	3003-01-RTG	10530637	3003-02-RTG
10230453	3003-01-RTG	10930154	3003-04-RTG
10230631	3003-01-RTG	10930166	3003-04-RTG
10330164	21-02G-RTG	10930457	3003-04-RTG
10330455	21-02G-RTG	10930635	3003-04-RTG