

# **ASSEMBLY INSTRUCTIONS**

# Description: Kelly Lounge Chair

#### Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

#### Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

## Parts List

ltem	Description		QTY
P1	Seat Cushion	$\langle \rangle$	1
P2	Back Frame		1
P3	Left Arm	A P3	1
P4	Right Arm	A P4	1

# Hardware List

ltem	Description		QTY
H1	Short Bolts Ø1/4"*1-1/4"	0	2
H2	Long Bolts Ø1/4"*1-1/2"		6
H3	Lock Washers 1/4"	Ø	8
H4	Small Flat washers 1/4"*12mm	0	4
H5	Big Flat washers 1/4"*19mm	0	4
H6	Wooden Plugs	0	4
H7	Allen Wrench 1/4"	L	1



## **Assembly Procedures:**

Step 1. Assemble the lounge on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach seat cushion (P1) with one located dowel to left arm (P3), please note the label "P3" on the left arm (P3) as shown below. Loosely tighten the bolts with Allen wrench (H7).







Step 5.

(H6)x4

- 1) Make sure the assembled lounge is level and s ecurely tighten all the bolts with Allen wrench (H7).
- 2) Attach wooden plugs (H6) to each exposed bolt holes, tighten with rubber hammer to knock the wooden plug till its tighten. **Note:** use a soft cloth between the wooden plug and hammer to prevent damage to wooden plug finish.
- 3) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.
  - Wooden Plugs

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase