




Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





Pre-assembly:

- Do not discard any content until assembly completed to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardwares from box.


Parts List

Item	Description		QTY
P1	Front legs		2
P2	Back legs		2
P3	Chair top		1


Hardware List

Item	Description		QTY
H1	Bolts M8 x 30mm		12
H2	Lock Washers 8		12
H3	Flat Washers 8		12
H4	Allen Wrench		1


Step 1. Assemble the Taylor Accent Chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.



Step 2: Attached the Front legs (P1) and Back legs (P2) to the seat frame by using Lock washers (H2), Flat wahers (H3) and Bolt (H1).



Step 3: Level the chair and place the chair upright on a level surface.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase