



ASSEMBLY INSTRUCTIONS

HLLC 9163-52 NON-PWR RECLINING LOVESEAT


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

TOOLS REQUIRED : NO TOOLS REQUIRED			
PART LIST			DUAL POWER RECLINER
A	LAF BACK		1
C	RAF BACK		1
D	SEAT		1
E	LAF WING		1
F	RAF WING		1



STEP 1: Attaching the KD backs


Position KD back with the KD receiver positioned over the mechanism post receiver on the back frame, pushing in a downward motion from the top of the back frame until a clicking sound is heard.




STEP 2 : Attach the KD Wings


Position the KD bracket on the wing so it is inside of the KD receiver on the back frame, push in a downward motion from the top of the back frame . Repeat the same step to attach the opposite side wing. See the illustration as right.

*Repeat the the above step to attach the KD backs to all of the sku's.






After assembly is complete your product should look as seen below.




WARNINGS

*Clearance to the wall 4.5 inches



*Avoid placing unit in areas where unit can be exposed to direct sunlight other powerful light sources,
*Keep unit at least 24" from all heat sources.


as fading or discoloration may occur.



*Do not reach under seat when mechanism is operating or serious injury may occur.
*Reclining mechanism should only be operated while seated properly.



Do not sit on arms or backrest
Do not jump or roughhouse on furniture



*If unit must be moved, do not drag. Unit must be lifted in order to be moved.



*Do not continuously operate mechanism for more than one minute or unit may go into protection mode by shutting down to prevent overheating.

*Unplug unit from power source prior to cleaning mechanism.

*Do not allow electrical components to come into contact with any liquids.

Trouble Shooting

Problem	Solution
No power	Check all power connections
No Reclining	Check all power connections
Headrest not working	Make sure headrest power cable is connected to chair cable
Lights not working	Check all power connections
USB not charging	Check all power connections Verify that USB cable is functioning
Backrest uneven	Ensure that seatback brackets are installed and locked in position(Step 1.2)

This product is manufactured by HLLC for

ROOMS TO GO® 