




REV 01



60672 Chair

PLEASE CONTACT US FOR QUESTIONS

Email our support team: help@ovis.co

- Read all instructions before assembling this product.
- Check this product for damaged hardware, loose joints, missing parts, or sharp edges after assembly and frequently during use.
- Do not use this product if any parts are missing, damaged, or broken.
- Properly discard all packaging materials after assembly is complete.
- This product contains small parts. Keep small parts out of children's reach during assembly.
- This chair is designed to be used by one individual at a time.
- When placing furniture on non-carpeted flooring, we recommend the use of floor protection such as an area rug or furniture pads.
- The maximum weight capacity of this chair is 300 lbs.
- Do not use this chair near fire or water.
- This product has moving parts, serious injuries can occur if not used appropriately.
- Do not sit on the edge of the seat, armrests, or backrest.
- Do not jump on chair.
- Do not use the chair as a step stool.
- Do not leave children unattended on or beside the chair.
- Do not let children play on or near the chair when in use. Serious injury can occur.



Estimated Time for Assembly

10:00 - 15:00




Weight Limitation

300 lbs



Tools Needed:

All Necessary Tools Are Included In The Package.

**Remove Inside Box And Hardware
From Seat Compartment**



PACKAGE CONTENT



C


M6 X 20
12 PCS




D

M6
1 PC


1



Attach legs "B" to bottom of seat "A" with "C" bolts to assemble. Tighten "C" bolt using "D".



2



Adjust the level glides in the bottom of legs to make the chair stable.

FOR ADDITIONAL HELP:

Email our support team: help@ovis.co