



ASSEMBLY INSTRUCTION


Accent Chair

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
A	 BOLTS	8	E	 FRONT LEG	2
B	 ALLEN WRENCH	1	F	 BACK LEG	2
C	 WASHER	8	G	 chair	1
D	 LOCK WASHER	8			

Step 1: Take out the legs and hardware package from the chair.



Step 3: Screw leg and in holes of chaise bottom completely according to indication marked on legs.



Step 3 Level the chair and place the chair upright on a level surface.

