






Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.


Parts List

Item	Description		QTY
P1	Front legs		2
P2	Left back leg		1
P3	Right back leg		1
P4	Chair top		1
P5	Seat Cushion		1






Hardware List


Item	Description		QTY
H1	Bolts 5/16"x 25mm		6
H2	Lock Washers 5/16"		6
H3	Flat Washers 5/16"		6
H4	Allen Wrench		1
H5	Plastic washer		2

Step 1: Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Remove the legs and hardware package from the chair top .




Step 2: Attach left back legs(P2) and right back legs(P3) to chair top(P4) using Allen wrench(H4), bolt(H1), lock washer(H2), flat washer(H3). Attach front legs(P1) into the holes on the bottom of chair top (P4) through plastic washer(H5).

- (H1)x 6 Bolts 5/16" x 25mm 
- (H2)x 6 Lock Washers 5/16" 
- (H3)x 6 Flat Washers 5/16" 
- (H4)x 1 Allen Wrench 
- (H5)x 2 Plastic washer 



Step 3: Turn the assembled chair to an upright position. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase