



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the HARDWARE LIST below.


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staple used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.


NO:	HARDWARE LISTS		Q'TY
A	Bolt (Ø5/16" x 18 x 25mm) (pre-assembled)		8
	Spring washer (Ø1/4"x 13 x 1.5mm) (pre-assembled)		
	Flat washer (Ø1/4" x 19 x 2mm) (pre-assembled)		
B	Allen key (4mm x 32 x 75)		1

NO:	PARTS LISTS		Q'TY
1	Bench		1
2	Leg		2


Step 1 Open the bench lid and take out the box containing the legs (2)





Step 2 Loosen the bolts and washers (A) pre-installed on the bottom of the bench (1) using an Allen key (B).



Step 3 Attach the leg (2) to the bench (1) using bolts and washers (A), then tighten using Allen key (B)



Completed



Caring for Your Furniture

To ensure your bench maintains its appearance, comfort, and durability for years to come, please follow these Care & Maintenance Guidelines.

The Enemies of Furniture

To extend the life of your bench, avoid exposure to these common threats:

- **Sunlight & Heat:** Prolonged exposure to direct sunlight or heat sources may cause fading, discoloration, or deterioration of upholstery materials.
- **Moisture:** Wipe up spills immediately and avoid placing the bench in damp or humid environments. Excess moisture may damage upholstery and the metal leg frame.
- **Harsh Chemicals:** Do not use bleach, ammonia, or solvent-based cleaners. Use only mild soap and water when necessary.
- **Sharp Objects:** Keep sharp or abrasive items away from the upholstered surface to prevent cuts, snags, or surface damage.
- **Uneven Surfaces:** Place the bench on a level surface to ensure stability and prevent stress on the metal leg frame and fasteners.

Tips for Better Maintenance

Simple care routines will keep your bench looking and performing its best:

- **Regular Cleaning:** Vacuum upholstery regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** Blot spills gently with a clean, damp cloth and mild soap. Do not rub. Allow to air dry completely.
- **Upholstery Care:** Avoid excessive pressure on one area to maintain the shape and structure of the bench.
- **Metal Leg Frame Care:** Wipe the metal leg frame with a soft, dry cloth. Avoid prolonged exposure to moisture to prevent corrosion.
- **Hardware Check:** Periodically inspect bolts to ensure the metal leg frame remains securely fastened.

With proper care, your bench will remain functional, comfortable, and visually appealing for years to come.

☞ For indoor residential use only.