








# ASSEMBLY INSTRUCTION

CVFNR4203


## PARTS

S.NO.	DESCRIPTION		QTY
D		MARBLE TOP	1
E		WOODEN TOP	1
F		LEG	1

## HARDWARE


S.NO.	DESCRIPTION		QTY
A		ALLEN BOLT 5x16mm	8
B		SPRING WASHER 5mm	8
C		WASHER 5mm	8
D		ALLEN KEY 4mm	1

### STEP -1




Note : Keep the marble top on soft surface.  
Don't make bolt tighten until wooden  
top assembled.

### STEP -2



Note : Now all bolts can be tightened.

### COMPLETED



Adjust height  
for balance

