


Item # : AF16GEOST

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage,
or request parts. www.walkeredison.com

Revised 11/07/2019(C)


General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product are: bolts and screws.
- V. Power tools should not be used to assemble this product.




- VI. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		M6*25mm	Bolt	12 pcs
B		M4	Hex key	1 pc



Philips head screwdriver required for assembly
(not included)



*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Using bolt (A) attach part (3) into part (2) with hex key (B) as per diagram.
Note: do not fully tighten all the bolts .

Step 2



Using bolt (A) attach parts (3) into part (1) with hex key (B) as per diagram. Then fully tighten all the bolts.

Step 3



Final Assembly