



Assembly Instruction

WI11914



PART LIST



Assembly Instruction


Hardware List

No.	SHAPE	DESCRIPTION	Qty.
1		M8x40mm Wood Dowel	12 Pcs
2		8x25mm Wood Dowel	32 Pcs
3		15MM Titus Mini Fix	16 Sets
4		M5x40mm Screw	6 Pcs
5		M3.5x16mm Screw	42 Pcs
6		M3x16mm Screw	4 Pcs
7		M4x30mm Screw	8 Pcs
8		M4x38mm Screw	10 Pcs
9		OS-V Handle	2 Pcs
10		Drawer Slide 300mm	2 Sets


11		M5x8mm Screw (Euro Screw)	8Pcs
12		Nail Leg	4 Pcs
13		L Bracket	14 Pcs
14		Z Bracket	2 Pcs
15		15mm Minifix Cap	8 Pcs

Packing Tipping Restraint

Hardware List


No.	SHAPE	DESCRIPTION	Qty.
16		M3.5x16mm Screw	2Pcs
17		Safety Strap	2Pcs
18		Wall Plug	2Pcs
19		M4x30mm Screw	2Pcs
20		Flat Washer 6x19x2mm	4Pcs

STEP 1




Assembly Instruction

STEP 2




STEP 3




Assembly Instruction

STEP 4




STEP 5




Assembly Instruction

STEP 6




STEP 7




Assembly Instruction

STEP 8




STEP 9




Assembly Instruction

STEP 10




STEP 11




Assembly Instruction

STEP 12




STEP 13




Assembly Instruction


STEP 14




STEP 15




FURNITURE TIPPING RESTRAINT




1. First mark the wall with pencil as in diagram.




2. Drill small hole at the pencil mark.




3. Insert plastic wall plug (18).




FURNITURE TIPPING RESTRAINT




4. Add safety strap (17), washer (20) using 3.5x16mm screw (16) to back of cabinet.



5. Finally, attach safety strap (17) and washer (20) using 4x30mm screw (19) to the wall.





⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">• ALWAYS install tipover restraint provided.• NEVER put a TV on this product.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heaviest items in the lowest drawers. <p><i>This is a permanent label. Do not remove!</i></p>
	



Anti-Topple hardware included for added safety and stability