


Assembly Instructions


903028 - 70" Lexington TV Stand - Dark Mocha

903029 - 70" Lexington TV Stand - Grey


Compatible with 26" Fireplace Insert - SKU 91226 (Sold Separately)

Product Issues? Please Call Us Before Contacting Your Retailer
At 1-800-549-3300, email customerservice@mshome.co, or visit mshome.co
We can help with Assembly Issues, Part Requests, Damages, & All Other
Product Related Questions








15 min





Two People Required



Phillips Head









PARTS INCLUDED:

- (C1) Top Panel X 1
- (C2) Middle Panel X 1
- (C3) Bottom Panel X 1
- (C4) Right Side Panel X 1
- (C5) Left Side Panel X 1
- (C6) Top Partition Panel X 1
- (C7) Right Partition Panel X 1
- (C8) Left Partition Panel X 1
- (C9) Right Back Panel X 1
- (C10) Left Back Panel X 1
- (C11) Center Back Panel X 1





ANTI-TIP SET

☒ Hardware Pack Located In Carton

<p>A</p>  <p>Ø6.3x60 (mm) : 4 pcs</p>	<p>B</p>  <p>Ø6.3x38 (mm) : 10 pcs</p>	<p>C</p>  <p>Ø6.3x20 (mm) : 10 pcs</p>	<p>D</p>  <p>Ø4x20 (mm) : 38pcs</p>
<p>E</p>  <p>Ø4x12 (mm) : 2 pcs</p>	<p>F</p>  <p>Ø10x40 (mm) : 13 pcs</p>	<p>G</p>  <p>50x30x20x1.2 (mm) : 2 pcs</p>	<p>H</p>  <p>Ø4 : 1 pc</p>

1

F x 10




2



C x 6



F x 1



H x 1




3

B x 6





H x 1



H

B



H


B

4


C x 4



F x 2




H x 1



C8


C7



F

H

C



5


A x 4



B x 4





H x 1



H

B

C3





H


A

6

D x 38




Phillips Head




C9

C11



C10




7




Phillips Head





Optional Fireplace Insert Installation Guide




Notice:

Please read all "Electric fireplace insert" instructions prior to installing electric fireplace insert in your completed tv stand. Install the insert in your fireplace close to its final position.

For all questions related to the electric fireplace including operation, troubleshooting, parts, or warranty, please refer to the "Electric fireplace insert" owner's guide.


9




Phillips Head




WARNING: Center back panel insert must remain unattached and removed from the case when the Fireplace insert is installed



10




Phillips Head




11


E x 2



G x 2



Phillips Head



12

