



888-230-2225 help@manhattancomfort.com




Liberty TV Stand 62.99

Model # 201AMC6, 201AMC63, 201AMC64, 201AMC67, 201AMC69, 201AMC8, 201AMC9, 201AMC93, 201AMC94, 201AMC96, 201AMC97









n.° ID	Parts Identification (Description)	Quantity
01	Base	1
02	Top Panel	1
03	Left Side Panel	1
04	Shelf	1
05	Partition	1
06	Right Side Panel	1
07	Door	2
08	Back Panel	1
09	Wood Feet	4



TOOLS NEEDED




INCLUDED IN THE HARDWARE




STEP 1 Bo A A Fix the feet (9) under the Base (01) with bolts (A). Apply the protective felt (K) on the bottom of the feet (09). Apply the plastic covers (B) on top of the bolts (A).






• Connect the Shelf (04) into Left Side Panel (03) and Partition (05) with dowels (C) and cam lock hardware (E + F).

STEP 3




STEP 4



• Connect Back Panel (08) with nails (H).

STEP 5



- Preparing the Doors (07):
 Insert the plastic ring (N) in the Doors (07).
- Fix the hinges (I) in the two Doors (07) with bolts (J), as shown in DETAIL 2.

