ASSEMBLY INSTRUCTIONS

LV28 TV 28120WI-CLB/GD




Thank you for you purchase.

Before assembly, please read these instructions.

Please read all warnings.

Store this instruction manual for future reference.

Product Size	Approximately 398 Width x 1200 Length x 850 Height (MM)		
Main Materials	MDF (Medium Density Fiberboard)		
Weight Capacity	Top insert: About 30KG, Shelf insert: About 10KG, X These are measured figures, not guaranteed figures.		
Time To Assembly	About 30 Minutes	Update Date	30/10/2021




Assembly Warning


- Assembling with 2 or more people is recommended.
- Please assemble at a spacious and flat place
- Please place blankets or cardboard so floor or walls will not be scratched
- Please ventilate the area if there is a strong glue odor after opening the product
- Please follow assembly instructions
- Please have the below tools ready before assembling
 - Screwdriver, Scissors or Blade Box cutter, Rubber hammer, Drill

Hardware


Before assembly, inspect unit for missing parts. Be sure that children do not accidentally swallow these parts. Same sized parts are in a bag. Please check the size of the screws.




Parts





Assembly Information





02






























Failure to follow these directions could cause poor strength or stability. Insert screws loose to line up with slots then tighten up each screw.


13



Installation:

As shown, use the srewdriver to make the screw goes into the hole until the screw is tight.

14




Installation:

As shown, the head of minifix housing goes into the open mouth of the mini fix bolt. Use Allen Key then turn the minifix housing so it tightens over the mini fix bolt.

Failure to follow these directions could cause poor strength or stability. Insert screws loose to line up with slots then tighten up each screw.

15



Installation:


As shown, use the hammer to make the power pin goes into the hole until the power pin is tight.


a # Make sure the non-wheeled part of the drawer is touching the front of the drawer.
Screws in holes a, b and c.
DL for left drawer
DR for right drawer
DR

Roller

10


Failure to follow these directions could cause poor strength or stability. Insert screws loose to line up with slots then tighten up each screw.






11

Failure to follow these directions could cause poor strength or stability. Insert screws loose to line up with slots then tighten up each screw.



20 COMPLETED



Safety

Please read the below warnings before use.

Failure to follow these warnings could result in serious injury.



CAUTION!!!

Purpose

- Do not use this unit except for original application
- This unit is for household use. Do not use it for wholesale.
- This unit is for indoor use. Do not use it outside.

Assembly

- Assembling with 2 or more people is recommended
- Please assemble at a spacious and flat place
- Please place blankets or cardboard so floor or walls will not be scratched
- Please ventilate the area if there is strong glue odor after opening the product
- Please follow assembly instructions

Placing The Unit

- Store the unit on a flat surface.
- Place a mat under the unit if you place it on wood floors for floor protection
- Do not place the unit in areas where conditions are extreme, such as direct sun or a humid place
- Do not place the unit in a hot or humid area, such as near the heater or fireplace

Usage

- Please check your surroundings when you use this unit
- Do not place any hot or wet objects on the unit
- Remove all objects on the unit when you move it
- Do not leave water or wet objects on the surface.
- Do not use it for toys
- Do not stand on it or use it for a step stool.
- Do not overload only the top drawers. Load the same amount to help prevent tipping of the unit.
- Do not leave drawers open or put pressure on opened drawers to help prevent falling or wrecking.
- Do not stand or put pressure on opened drawers.
- Colors could fade
- Please open drawers slowly
- Make sure you do not catch your finger when you use the drawer.
- Weight Capacity Top insert: About 30KG,
 Shelf insert: About 10KG,
 These are measured figures, not guaranteed figures

Cleaning

- Please check all assembled parts are tight regularly. (About once a month)
- Use dry soft cloths for dust and spots
- For heavy spots, use clothes with neutral detergent then dry in a well ventilated area.
- Do not use if any parts are broken.
- Please recycle the unit or its package depending on your city rules.


HOW TO ADJUST GLASS/DOORS


•


There is a gap in the middle with doors closec

• There is a gap between the door and the shelf with doors closed


supporting the doors, adjust the door by moving it back and forth, then tighten the back Loosen the back adjustable screw which is one of the two screws looking from the front while








the middle gap. After adjusted, tighten the ① screw. the front while supporting the doors, tighten the ② screw clockwise, then adjust Loosen the 1 back adjustable screw which is one of the two screws looking from



(Glass slide hinge does not require this step) There is a gap on the top of the door when doors are closed

it up and down then tighten the screws. Loosen the slide hinge screw while supporting the door, adjust the door by moving (4 screw hole hinge does not require ①)

before moving it up and down.) (Please loosen the slide hinge screws of the door completely you are adjusting




the top of the door If there is a gap on

these screws before adjusting)

There is a V gap when doors are closed

middle gap. After adjusted, tighten the ① screw. front while supporting the doors, tighten the ② screw clockwise, then adjust the Loosen the 1back adjustable screw which is one of the two screws looking from the



Page 15 of 15 Printed On 09-12-2021 5:10:28 PM