




Assembly Instructions






ITEM NO.:40271

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)

PARTS LIST:

NO.	Description	Sketch	Quantity
A	Top		1pc
B	Legs		2pcs
C	Center Legs		4pcs

HARDWARE LIST

NO.	Sketch	Description	Size	Quantity
D		Blots	Ø1/4"*1-5/8"L	4pcs
E		Flast washer	Ø1/4"	4pcs
F		Look washer	Ø1/4"*5/8"	4pcs
G		Allen wrench	M4*65L	1pc
H		Blots	Ø1/4"*1/4"L	8pcs

