
#### Item #: B44CORSW

**Assembly Instruction** 





Please visit our website for the most current instructions, assembly tips report damage, or request parts. www.walkeredison.com


Revised 11/2019


### **General Assembly Guidelines**

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.



VI. Power tools should not be used to assemble this product.





### **Hardware List**

Α		Ø 5,5x28mm	Cam Bolt	08 pcs
В		Ø 14x14mm	Cam Lock	08 pcs
С		Ø 3,5x14 mm	Screw	02 pcs
D		Ø 8x30 mm	Wood dowel	28 pcs
Е		Ø 3,5x30 mm	Screw	16 pcs
F	Expanding and appropriate the second of the	Ø 4x40mm	Screw	08 pcs
G		Ø 3,5x16 mm	Screw	24 pcs
Н			Washer	01 pc
1			Hinge	02 pcs
J			Latch	01 pc
K			Latch Stop	01 pc
		Philips head screwdriver required for assembly		


The hardware quantities listed above are required for proper assembly.


Some extra hardware may also have been included.


(not included)


# Step 1 (2x) G 6 D **(5)** 4 Ø 8x30 mm


## Step 2















## Step 7



### Step 8

