










ASSEMBLY INSTRUCTIONS

ITEM NO.:51550


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)

PARTS LIST:				HARDWARE LIST				
NO.	Description	Sketch	Quantity	NO.	Sketch	Description	Size	Quantity
A	Top		1	E		Blots	Ø5/16"*1-3/4"	8
B	Front Right Legs		2	F		Flast washer	Ø5/16"*1/2"	8
	Front Left Legs			G		Look washer	Ø5/16"*3/4"	8
C	Back Left Leg		1	H		Allen wrench	M5*65L	1
D	Back Right Leg		1					



Tips: for a aligning doors:

Tip A: Sometimes the doors will not line up because of an uneven floor surface the furniture reats on. In that case, try adjusting the levelers found on the bottom of each foot to aid in corecting.



Tips: for a aligning doors:

Tip A: Sometimes the doors will not line up because of an uneven floor surface the furniture reats on. In that case, try adjusting the levelers found on the bottom of each foot to aid in corecting.

