

Assembly Instructions

22033360 COFFEE TABLE


Product Issues? Please Call Us Before Contacting Your Retailer At 1-800-549-3300. Email customerservice@ mshome.co, visit www.mshome.co
We can help with Assembly Issues, Part Requests, Damages, & All Other Product Related Questions




MSH-USA




6 min



One Person for Assembly







Do not use power tools




PARTS INCLUDED

- (C1) Wood Top x1
- (C2) Rattan Base x1







☑ Hardware Pack

A  2pcs	B  2pcs	C  1pc


1

A x 2	B x 2	C





2



Replacement Part Form

Have an issue? Need a replacement part?

Please E-mail us before contacting your retailer, we will be happy to fix your issue.

This process will be hassle free! We will replace your part for free!

Please follow these easy steps below.

You will need to E-mail *Martin Svensson Home* Customer Service: Customerservice@mshome.co (Please note it is .CO not .com)

Please scan or take a picture of this form filled out.

1. **Customer Name:** _____
2. **SKU# with issue:** _____
3. **Replacement Part # needed** _____
   ***Please reference the Assembly Instructions to identify needed part #'s**
4. **Photos of the Damaged Part (please include in the e-mail)**
5. **Brief description of the part issue:** _____
6. **Proof of Purchase (please provide a copy of your purchase receipt)**
7. **Ship to Address:** _____
   _____
   _____
8. **Other contact information:**
   Email Address _____
   Phone # _____

*** If possible, could you please provide the UPS or FedEx tracking for original shipment** _____

***If possible, could you please provide PO # information found on back underneath product** _____

***If you have any other questions, we are happy to assist with assembly questions and all other parts related questions. Thank you for your purchase!**