



# Assembly Instructions

RETG 1422-30 CHAIRSIDE TABLE - SKU# 23114200

Manufactured by RETG for Rooms To Go

Version#1 - 10/07/2025

**\*\*\* Caution : Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assemble.**

## PARTS LIST

No.	Description	Sketch	Q'ty
1	Table top		1 Pc
2	Table base		1 Pc
3	Right Table legs		2 Pcs
4	Left Table legs		2 Pcs

## HARDWARE LIST

No.	Description	Zize	Sketch	Q'ty
A	Allen Key Z	M4		1 Pc


HARDWARE LIST			Q'ty
Pre-installed on Part 1&2	Allen Bolt Ø5/16" x 18 x 2-1/4" Pre-installed		12 Pcs
	Spring Washer Ø5/16" Pre-installed		12 Pcs
	Flat Washer Ø5/16" Pre-installed		12 Pcs
	Threaded Washer Ø5/16"- 18 x 10mm Pre-installed		12 Pcs

Remark:


+ Do not fully tighten all bolts until assembly is complete

### STEP 1:

Place the Table top (1) on a padded area, Remove the drawers from the table top: Fully extend the drawer, then press the plastic tab down on the right and up on the left at the same time as shown below. While holding the tabs pressed down/up, pull the drawer out.



**STEP 2:** Flip the table top (1) upside down. Place a blanket or some form of padding underneath of the top when placing on a hard surface to avoid scratches. Place Right Table legs (3) and Left Table legs (4) so that it fits the redetermined pin holes in back panel of Table top (1). Use an Allen key Z(A) to tighten the bolts which were pre-installed on the table corners.



### Hardware Pack Location (s):

RETG 1422-30 CHAIRSIDE TABLE - SKU#23114200



# Assembly Instructions

RETG 1422-30 CHAIRSIDE TABLE - SKU# 23114200


Manufactured by RETG for Rooms To Go

Version#1 - 10/07/2025

**\*\*\* Caution : Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assemble.**


### STEP 3:

Turn the Table base (2) upside down into the holes marked on the Right Table legs (3) and Left Table legs (4) assembly. Use the Z-wrench (A) to tighten the bolts that are already installed on the table corners.



### STEP 4:

Turn the table to the upright position.  
Re-installed all the drawers in the table top. Fully extend the slides from the case. Then align the slides on the drawer to the slides on the case as shown. Push the drawer back in. You may have to slide the drawer in and out several times in order to properly align the ball bearings.



COMPLETE ASSEMBLY

### Hardware Pack Location (s):

RETG 1422-30 CHAIRSIDE TABLE - SKU#23114200

# INSTRUCCIONES DE SEGURIDAD IMPORANTES



## WARNING

**El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA**

125 VOLTS AC /12 AMPERES / 1500 WATTS

Miézo Inc.  
PDU-111-00B

### **Leer todas las instrucciones antes de usar este mobiliario.**

#### **PELIGRO - Para reducir el riesgo de descarga eléctrica:**

- Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo

#### **ADVERTENCIA: para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:**

- Desenchufe del tomacorriente antes de colocar o quitar partes.
- Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
- Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor
- Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
- Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
- No fuerce ni estire el cable eléctrico.
- No utilizar cables de extensión o tomas de corriente.
- Mantener fuera del alcance de los niños. Esto no es un juguete
- Enchúfelo directamente a una toma de corriente compatible.
- No modifique el enchufe ni utilice adaptadores.

# IMPORTANT SAFETY INSTRUCTIONS



## WARNING

**Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK**

125 VOLTS AC /12 AMPERES / 1500 WATTS

Miézo Inc.  
PDU-111-00B

### **Read all instructions before using this furnishing.**

#### **DANGER – To reduce the risk of electric shock:**

- Always unplug this furnishing from the electrical outlet before cleaning or servicing.

#### **WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:**

- Unplug from outlet before putting on or taking off parts.
- Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
- Keep the electrical cord and plug away from heated surfaces and other heat sources.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
- Do not strain or stretch electrical cord.
- Do not use extension cords or power strips.
- Keep out of reach of children. This is not a toy.
- Plug directly into a compatible electrical socket.
- Do not modify the plug or use any adapters.