


ASSEMBLY INSTRUCTION


TCHI 1425-03 SOFA TABLE SKU#23814254


*** Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

PARTS LIST




HARDWARE LIST





STEP 1

Place table top (A) upside down on a clean carpeted surface, then loosely attach legs (B) to table top (A) with flat washers (3), spring washers (2), and hex socket head bolts (1), using Allen Key (4). DO NOT fully tighten, the flexibility will help assembly in the following steps.






ASSEMBLY INSTRUCTION

TCHI 1425-03 SOFA TABLE SKU#23814254

*** Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

STEP 2

Attach stretcher (C) to legs (B) with flat washers (5), spring washers (2), and hex socket head bolts (1), using Allen key (4).




STEP 3

Tighten all the bolts used in the above steps.

STEP 4

Attach plugs (6) to the stretcher (C).



STEP 5

Turn the assembled table upright. If needed, adjust the levelers underneath table legs to level with floor.

CLEANING INSTRUCTION: Clean with a soft cloth and warm water with a diluted mild detergent. Follow with a soft cloth and clear water rinse, then dry thoroughly with a soft cloth.