

Thank you for purchasing this quality product. Be Sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

(Note : Loosely thread all screws / bolts first. Once the Item is assembled then completely tighten)

PARTS LIST :


S. NO.	DESCRIPTION	SKETCH	QTY
1	IRON LEGS		2
2	WOODEN TRAY		6
3	SUPPORT STRIP		2

Allen Bolt Thread Count is 17 to 18
Allen Bolt Length is 18MM, excluding the top head


HARDWARE LIST :

S. NO.	DESCRIPTION	SKETCH	SIZE	QTY
1	BOLT		6/16"	28+(1) extra
2	ALLEN KEY		4 MM	1
3	WASHER		1/2 "	28+(1) extra

STEP : 1 Fix wooden trays with iron legs match the wooden tray holes & iron legs holes as shown in Image with the help of D nut and Allen key.



STEP : 2 Fix support rod behind the book shelf with help of D Nut & Allen Key match the holes properly as shown in picture



Tip A: Sometimes the furniture will not balance because of an uneven floor surface it rests on. In that case, try adjusting the levelers found at the bottom of each foot to aid in balancing.

FINISH