

TV CONSOLE

ASSEMBLY INSTRUCTIONS MODEL No. AVA449-161

Important: Be sure to check all packing material carefully for small parts which may come loose inside carton during shipment. Separate, identify and count all parts and metal hardware.

Compare with part list and hardware illustrations to be sure all parts are present. If any part(s) is missing or damaged, contact your dealer's customer service department. For efficient and fast service, please indicate the model number and the parts needed.

ATTENTION: Some lettered parts listed on the instruction sheets may not be in the parts bag, they may already be assembled.

TOOLS REQUIRED

(Not included)
Phillips Screwdriver


HARDWARE:




BOLT CH. TRUSS
8/32X7/8 ZINC
Part No. Hcpp-078Z
Qty: (6 pc.) **INSTALLED**



H-0488-TIP Bracket Set
Part No. HB-488
Qty: (1 pc.)





PULL Satin Zinc
Part No. HBJ-CH3800SZ
Qty: (3 pc.) **INSTALLED**




10MM HOLE PLUG BROWN
Part No. HCPH-H
Qty: (2 pc.) **INSTALLED**

INSTRUCTIONS SHEET


ADJUSTABLE WOOD SHELF



STEP 1.



STEP 2.



STEP 3.