




Assembly Instructions

HMIS E105-76 76" CONSOLE SKU# : 24110506

***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and ensure the parts are not damaged during the assembly

Code	PARTS LIST:		
A	Console		1Pc

Step	Code	Hardware List		
1	B	Furniture Tipping Restraint		1Set

TOOLS REQUIRED (NOT PROVIDED)	
Description	Sketch
Phillips screwdriver	

⚠ WARNING - For use with televisions weighing 110lbs. /49.9 Kgs or less. Use with heavier televisions may result in instability causing tip over resulting in death or serious injury

Plasma/LCD-flat panel TV screen of various screen size to a maximum TV screen size 82 inches.

Each drawer should not be loaded more than 25 lbs. /11.3 Kgs each. Each shelf should not be loaded more than 25 lbs. /11.3 Kgs

DO NOT EXCEED RECOMMENDED LOAD. Use with products heavier than the maximum sizes and weights indicated may result in instability causing possible injury.


Do not allow children under 16 years to move unit
Always place TV no more than two inches from the back edge of the console. Placing TV more than two inches from the back edge may increase the risk that the console will tip over

DO NOT REMOVE THIS LABEL

⚠ WARNING - Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child."

⚠ WARNING - Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto the child."

Step 1 :RECOMMENDED: Install the anti-tipping kit(B).



This product is manufactured by HMIS for

ROOMS TO GO ▶

MADE IN VIETNAM

1 OF 1