






1 Slide upward the Guillotine back using the handle.



2 Remove shelf.




3 A) - Remove shelf supports (n° 4 pieces and n° 2 partition's hardware).
B) - Remove any hardware - the holes must be open (n° 2 partition's hardware)






4 Place the electrical appliance and push it into the compartment.



5 Replace the Guillotine back using the handle.



6

