



Components and Hardware List for SKU No. 79732

 = 15 min


Desk (1 pc)		Legs (2 sets)	
Bolt	Washer	Spring washer	Allen key
∅ 0.3 * 2" (6 pcs)	∅ 0.31" (6 pcs)	∅ 0.31" (6 pcs)	0.2" (1 pc)
Extra = 1 pc	Extra = 1 pc	Extra = 1 pc	

Instructions to Assembly


- Carefully remove all parts from the carton. Lay them out on a clean soft surface.
(Do not discard any packing materials until the product is fully assembled, to prevent any small parts from being accidentally discarded.)
- Lay the Desk upside down on a clean soft surface or fabric. (Pic.1)
- Take each leg set and match it with the corresponding letter.
Align the set's screw holes with the desk's screw holes. (Pic.2)
- Place spring washer & flat washer before inserting the bolt into the holes.
Screw and tighten each bolt by provided Allen key. (Pic.3)
- After securing the legs set, carefully turn the desk upright onto its legs




Pic. 1




Pic.2



Pic.3



Pic.4



Pic.5

Usage Instructions:

- Clean your furniture regularly with dry cloth and any good quality furniture wax.
- Use trays or coasters to prevent heat marks from occurring on the furniture .
- Avoid keeping your furniture next to windows and other places directly exposed to sunlight to prevent its color fading.
- Wipe off any excess water or spilled liquid immediately to prevent water marks.