


ASSEMBLY INSTRUCTIONS


TCHI 7368-2 MIRROR SKU #32273687
TCHI 7368-1 DRESSER SKU# 32173685

*** Thank you for purchasing this quality product. Be sure to check all packaging materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list / hardware list below.

PARTS LIST


1	2
	
Mirror: 1pc	Mirror Support Rail: 2pcs

HARDWARE LIST

A		B	
M6x35mm Bolt : 8pcs	Spring Washer: 8pcs	Flat Washer: 8pcs	M4 Allen Key : 1pc

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast and easy assembly.



Hardware Pack Location: Inside Mirror

MIRROR , SKU #32273687 & DRESSER, SKU #32173685


ASSEMBLY INSTRUCTIONS

TCHI 7368-2 MIRROR SKU #32273687

TCHI 7368-1 DRESSER SKU# 32173685

*** Thank you for purchasing this quality product. Be sure to check all packaging materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with with the parts list.

STEP 2



Assembly is completed.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective.
Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

CLEANING INSTRUCTION:

Clean with a soft cloth and warm water with a diluted mild detergent.
Follow with a soft cloth and clear water rinse, then dry thoroughly with a soft cloth.