

Assembly instructions for

RIEE: 32375924
32475926

Lighted Uphl QN HDBD 7592-140
Lighted Uphl KG HDBD 7592-143

PAGE 1 OF 5


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.





1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.



WARNING: To avoid serious personal injury:


- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. This furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

NO.:	HARDWARE LIST (7592-140/ 143)		Q'TY
1		(L57x4MM) ALLEN KEY	1 piece


NO.:	PARTS LIST		
A		Headboard	1 piece
B		Headboard legs (Left)	1 piece
C		Headboard legs (Right)	1 piece
D		Headboard Bottom Stretcher	1 piece

STEP 1

Bolts are pre-installed on bed posts:
Bolts: 5/16" x 18 x 2" L
Flat Washer: 5/16" x Ø19mm x 1.2mm T
Spring Washer: 5/16" x Ø13mm x 1.2mm T



STEP 2



Bolts are pre-installed on HB bottom stretcher
Bolts: 1/4" x 20 x 1-1/2" L
Flat Washer: 1/4"
Spring Washer: 1/4"



Assembly instructions for

RIEE: 32375924
32475926

Lighted Uphl QN HDBD 7592-140
Lighted Uphl KG HDBD 7592-143

PAGE 2 OF 5

STEP 3



FCC instruction

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Customer Service

Supplier : EYUE Technology Co., Ltd

Tel : 1-800-990-9591

Email : info@eyuetech.com

Address : Responsible Party-U.S. Contact Information Furntron

800 N. Rainbow Blvd. Suite 211 Las Vegas, NV 89107 U.S.A.

Assembly instructions for

32375924/32475926
RIEE: 32775922/32875924
32975926

Lighted Uphl QN & KG HDBD 7592-140/ 143
QN & KG Panel FTBD 7592-141/ 144
QN & KG RSV Rails 7592-142

PAGE 3 OF 5


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.













WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. This furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.


NO.:	HARDWARE LIST (7592-140/ 143)		Q'TY
1		(L57x4MM) ALLEN KEY	1 piece

NO.:	HARDWARE LIST (7592-141/ 144)		Q'TY
2		8*30MM SCREW	10 pieces

NO.:	PARTS LIST		
A		Headboard	1 piece
B		Headboard legs (Left)	1 piece
C		Headboard legs (Right)	1 piece
D		Headboard Bottom Stretcher	1 piece
E		Footboard	1 piece
F		Side rail	2 pieces
G		Bed Slat	5 pieces
H		Long slat support leg	10 pieces
I		Short slat support leg	10 pieces



Option 1: Low Mattress Position



Option 2: High Mattress Position

Assembly instructions for


32375924/32475926
RIEE: 32775922/32875924
32975926

Lighted Uphl QN & KG HDBD 7592-140/ 143
QN & KG Panel FTBD 7592-141/ 144
QN & KG RSV Rails 7592-142


PAGE 4 OF 5

The reversible siderails can be set up 2 options for mattress position.

Option 1: The cleats support slat are at low position so that the mattress is at low position.
You will need just the long slat supports for this option.



Option 2: The cleats support slat are high position so that the mattress is at high position. You will need both long & short slat supports for this option. The long & short supports are connected together before connect to the bed slats.



Assembly completed

Assembly instructions for

RIEE: 32375924/32475926
32775922/32875924
32975926

Lighted Uphl QN & KG HDBD 7592-140/ 143
QN & KG Panel FTBD 7592-141/ 144
QN & KG RSV Rails 7592-142

PAGE 5 OF 5



WARNING

Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK

[ELECTRICAL RATING (12V/2A/24Watts)]
[Eyue Technology Co., Ltd]
[FX24U-120200C]

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.



WARNING

El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

[CLASIFICACION ELECTTRICA ((12V/2A/24Watts))]
[Eyue Technology Co., Ltd]
[FX24U-120200C]

Leer todas las instrucciones antes de usar este mobiliario.

PELIGRO - Para reducir el riesgo de descarga eléctrica:

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA: para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.