



Manufactured by PNWD for Rooms To Go

ASSEMBLY INSTRUCTION


PNWD 3230-NS NIGHTSTAND USB/LED - SKU: 32532308

Version #1 - 2024/12/24

THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIALS CAREFULLY FOR SMALL HARDWARE WHICH MAY HAVE COME LOOSE INSIDE THE CARTON DURING SHIPMENT. IDENTIFY AND COUNT ALL HARDWARE AND COMPARE WITH THE HARDWARE LIST BELOW.

TOOLS REQUIRED (NOT PROVIDED)

Screwdriver





PARTS LIST :

No.	Description	Sketch	Q'ty
A	Nightstand		1

HARDWARE LIST :


NO.	HARDWARE LIST	Q' TY
1	Anti-tipping hardware	1




CAUTION: Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Remark:
Anti-tipping hardware - customer assembly required



REMARK: Tip restraint kit provided MUST be installed to solid wood back frame only . DO NOT install to PB top panel or MDF back panel.

**Hardware Pack Location: Anti-tipping hardware > Placed at inside top drawer
3230-NS Nightstand USB/LED , SKU : 32532308**

ENGLISH

IMPORTANT SAFETY INSTRUCTIONS



WARNING

Misuse can result in FIRE or Death by ELECTRICAL SHOCK

[ELECTRICAL RATING (100-240V 50/60HZ 0.5A, OUTPUT: DC 5V 2.5A)]

[VANTAGE CITY GROUP LIMITED]

[VAN-050250PS-A]

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons :

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect , turn all controls to the off position , then remove plug from outlet.
5. When operating , ensure that electrical cord is not under the base , legs , or motion mechanism to a void damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children . This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters .

SPANISH

INSTRUCCIONES DE SEGURIDAD IMPORANTES



WARNING

El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

[ELECTRICAL RATING (100-240V 50/60HZ 0.5A, OUTPUT: DC 5V 2.5A)]

[VANTAGE CITY GROUP LIMITED]

[VAN-050250PS-A]

Leer todas las instrucciones antes de usar este mobiliario.

PELIGRO- Para reducir el riesgo de descarga electrica:


1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA: para reducir el riesgo de quemaduras , incendios, descargas eléctricas o lesiones a personas:

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua . Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen .
3. Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente .
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe .
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores .


INSTRUCTION FOR DUAL USB CHARGER WITH LED LIGHT

STEP 1




Insert LED light USB cable port into the base of dual USB charger hub.

STEP 2



Insert USB cable port from dual USB charger hub into power adapter. Next plug adapter into electrical outlet for power source.

STEP 3



Both USB ports & LED light are now powered on and ready to charge devices.


STEP 4 – NIGHT FEATURE



Power on/off button for LED lighting with blue light

Press power button to turn on LED light. Blue light indicator in USB charging ports will appear. Press power button again to turn off.

STEP 5




LED light can be adjusted to desirable position. Take note, this lighting is LED, not conventional light bulb.

CAUTION: Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

USB CHARGER WITH LED LIGHT DIAGRAM



For direct service pertaining charging stations please contact
Vantage customer service at 844-244-3810