


**Churra Sheepskin Bench**  
**TOV-088**




# **CHURRA**

---






## **ASSEMBLY INSTRUCTIONS**



## PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
<b>A</b>		<b>BENCH</b>	<b>1</b>
<b>B</b>		<b>Right Leg</b>	<b>2</b>
<b>C</b>		<b>Left Leg</b>	<b>2</b>

## HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
<b>D</b>		<b>Metal Gasket</b>	<b>12</b>
<b>E</b>		<b>Spring Washer</b>	<b>12</b>
<b>F</b>		<b>Screw</b>	<b>12</b>
<b>G</b>		<b>Wrench</b>	<b>1</b>
<b>H</b>		<b>Plastic Gasket</b>	<b>12</b>

### BEFORE BEGINNING ASSEMBLY:



*Read instructions cover to cover*



*Have two adults on hand for assembly*




*Do NOT assemble on flooring or carpet. Assemble on a clean non-marring surface (ex: packing foam)*



*Save all packaging until assembly is completed*


# ASSEMBLY STEPS

## STEP 1



- › Position the product on its bottom as shown.
- › Open to take the four legs.

## STEP 2



## **CARE & MAINTENANCE**



**Do not put hot items directly on furniture surface.**



**Do not clean furniture with harsh cleansers or polish.**



**Dust and pick up spills using a clean, non-colored, lint-free cloth.**



**Stains may be removed with mild soap solution and a damp cloth.**



**Do not place furniture under direct sunlight.**



**Do not place furniture near heating or cooling vents.**



**Do not write on furniture without a padded barrier to protect the surface.**



**Do not place furniture outside, for indoor use only.**