



ALYSSA TWIN LIGHTED BED



High Mattress Position



Low Mattress Position

3407591P- TWIN LIGHTED BED - WHITE



SKU#	STYLE	COLOR	ITEM DESCRIPTION
34675910	7591-145	WHITE	TWIN UPHOLSTERED HEADBOARD
34775912	7591-146	WHITE	TWIN PANEL FOOTBOARD
35075919	7591-147	WHITE	TWIN / FULL RAILS

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by RIEE for **ROOMS TO GO** | **KIDS**

ALYSSA TWIN LIGHTED BED

HEADBOARD PRE- ASSEMBLED HARDWARE LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
4	(Ø5/16*18*2"L) BOLT		6 PCS
	(Ø5/16*13*1.2MM) SPRING WASHER		6 PCS
	(Ø5/16*19*1.8MM) FLAT WASHER		6 PCS
	(Ø5/16-18X10MM) THREADED WASHER		6 PCS
5	(Ø1/4*20*1-1/2"L) BOLT		2 PCS
	(Ø1/4*13*1.2MM) SPRING WASHER		2 PCS
	(Ø1/4*19*1.8MM) FLAT WASHER		2 PCS
	(Ø1/4-18X10MM) THREADED WASHER		2 PCS
6	(Ø5/16*18*1"L) BOLT		4 PCS
	(Ø5/16*13*1.2MM) SPRING WASHER		4 PCS
	(Ø5/16*19*1.8MM) FLAT WASHER		4 PCS

FOOTBOARD PRE- ASSEMBLED HARDWARE LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
6	(Ø5/16*18*1"L) BOLT		4 PCS
	(Ø5/16*13*1.2MM) SPRING WASHER		4 PCS
	(Ø5/16*19*1.8MM) FLAT WASHER		4 PCS

HEADBOARD HARDWARE LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
1	(L57x4MM) ALLEN KEY		1 PC

FTBD HARDWARE LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
2	8*30MM SCREW		10 PCS
3	PHILIPS SCREWDRIVER (NOT PROVIDED)		

TWIN UPHOLSTERED HEADBOARD PARTS LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
A	TWIN UPHOLSTERED HEADBOARD		1 PC
L	HEADBOARD LEG (LEFT)		1 PC
R	HEADBOARD LEG (RIGHT)		1 PC
D	BOTTOM STRETCHER		1 PC

TWIN PANEL FTBD PARTS LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
E	TWIN PANEL FOOTBOARD		1 PC
F	BED SLAT		5 PCS

TWIN & FULL RAILS PARTS LIST

	ITEM DESCRIPTION	IMAGE	Q'TY
G	TWIN/FULL SIDE RAILS		2 PCS


DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by RIEE for **ROOMS TO GO** | **KIDS**

ALYSSA TWIN LIGHTED BED


HARDWARE PACK LOCATION

SKU#	STYLE	COLOR	ITEM DESCRIPTION
34675910	7591-145	WHITE	UPHOL TWIN HDBD



HARDWARE PACK LOCATION

SKU#	STYLE	COLOR	ITEM DESCRIPTION
34775912	7591-146	WHITE	TWIN PANEL FTBD



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.


This product is manufactured by RIEE for **ROOMS TO GO** | **KIDS**

ALYSSA TWIN LIGHTED BED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.


Assembly instructions:

STEP 1



Attach the Stretcher (D) to the Headboard Legs (R) & (L). Tighten with Allen Bolts, Spring Washers, Flat Washers and Threaded Washers(5) with Allen Key provided (1) by screwing them into place.

STEP 2



Attach the Headboard Leg (L) & (R) to the Headboard (A). Tighten with Allen Bolts, Spring Washers, Flat Washers and Threaded Washers(4) with Allen Key provided (1) by screwing them into place.

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by RIEE for **ROOMS TO GO** | **KIDS**


ALYSSA TWIN LIGHTED BED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly instructions:


STEP 3

Lower Position



Low Mattress Position

Higher Position




High Mattress Position

Attach the Side Rails (G) to the Headboard Legs (R) & (L) and Footboard (E). Tighten with Allen Bolts, Spring Washers(6) and Flat Washers with Allen Key provided (1) by screwing them into place.


STEP 4

Low Mattress Position



Low Mattress Position

High Mattress Position



High Mattress Position

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.


This product is manufactured by RIEE for **ROOMS TO GO** | **KIDS**

ALYSSA TWIN LIGHTED BED

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly instructions:

STEP 5



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by RIEE for **ROOMS TO GO® | KIDS**

IMPORTANT SAFETY INSTRUCTIONS



WARNING

Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK

[ELECTRICAL RATING (12V/2A/24Watts)]

[Eyue Technology Co., Ltd]

[FX24U -120200C]

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.

INSTRUCCIONES DE SEGURIDAD IMPORANTES



WARNING

El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

[CLASIFICACION ELECTTRICA (12V/2A/24Watts)]

[Eyue Technology Co., Ltd]

[FX24U -120200C]

Leer todas las instrucciones antes de usar este mobiliario.

PELIGRO - Para reducir el riesgo de descarga electrica:

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA: para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.