


CARBON OPTIX										
FULL STORAGE BED										
3417181P FULL STORAGE BED - 34871815, 34971817, 35071810										
34	34871815 CARBON OPTIX PAINTED BLACK						7181-470 FULL STORAGE HEADBOARD			
34	971817	CARBON OPTIX			ск	7181-480 FULL PANEL FOOTBOARD W / SLATS				
35	35071810 CARBON OPTIX PAINTED BLACK					7181-350 TWIN / FULL SIDE RAILS				
SIDE RAIL PART LIST						HEADBOARD PART LIST				
	ITEM DESCRIPTION			IMAGE QTY			ITEM DESCRIPTION         IMAGE         QTY			
E					2 PCS	A	HEADBOARD		1 PC	
OPTIONAL PART LIST ITEM DESCRIPTION IMAGE QTY								et al a construction of the second se		
F	DEVEDSIBI E UNDERBED		IMAGE		1 PC	В	E701 REMOTE CONTROL WITH LITHIUM BATTERY Type:CR2025		1 PC	
						NC CU	NOTE : "LOST YOUR REMOTE" CONTACT ROOMS TO GO CUSTOMER CARE TO PURCHASE A REPLACEMENT			
~	THE COMPANY				1.7.0	FOOTBOARD PART LIST				
G	TWIN STORAGE TRUNDLE				1 PC	-	ITEM DESCRIPTION	IMAGE	QTY	
						с	PANEL FOOTBOARD		1 PC	
						D	SLATS		5 PCS	
	DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST									
T V	This product is manufactured by (HILB) for ROOMS TO GO       KIDS         Version #2 - 2023/05/03       1									







# Wooden Furniture Care

### **Protect Your Investment**

The beauty of furnishing care is that it helps to protect your investment. Fine furniture is an important purchase. Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

#### **Caring For Furniture**

Caring for furniture is easy. Following a few simple guidelines will help extend the life of your furniture.

\*Always dust with a polish moistened cloth. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch the furniture surface if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics

\*Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood, causing damage.

#### The Enemies of Furniture

Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.

\*Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight, use sun screening drapes during intense sunlight hour, rotate furniture in place and in room arrangements.

\*Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses saucers under cups and flowerpots. If a spill occurs, immediately blot it gently without rubbing the surface.

\*Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective pads under hot dishes, utensils or cooking appliances.

\*Cyclic changes in temparature can damage furniture. I-lot blasts of air such as those found from central heating should be avoided because they cause extreme localized drying of the wood.

## Tips for Better Dusting

\*Be sure in use the sauce type of polish consistently. Your furniture will appear cloudy or streaky if oil based and wax-based polished are interchanged.

\*Always use a fine furniture polish when dusting. Never dry dust, as it could cause microscopic scratches on your furniture surface. Remember to change dusting clothes frequently since a dirty cloth may scratch your furniture's surface.

\*Spray your furniture surface evenly, but not too generously. Wipe in a circular motion with a soft, clean cloth to clean and loosen the old polish.

\*Then, buff until completely dry for a beautiful shine and a smudge-resistant finish. For wood trim, spray polish on the cloth first, and then dust.