
NORTHRIDGE DRIVE FULL BED



3417203P FULL BED - CARAMEL		
RTG SKU#	KU# STYLE# ITEM DESCRIPTIO	
34872033	7203-460	FULL HDBD/FTBD & SLATS
35072038	7203-350	TWIN /FULL RAILS

OPTIONAL PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY
Н	REVERSIBLE UNDERBED STORAGE DRAWERS		1 PC
I	TRUNDLE		1 PC


HEADBOARD, FOOTBOARD PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY
A	HEADBOARD		1
В	HEADBOARD LEG (L/R)	····	2
C	FOOTBOARD		1
D	SLATS		5
		~	
Е	SHORT SUPPORT LEG		5

	TWIN / FULL SIDE RAIL PA	ART LIST	
	ITEM DESCRIPTION	IMAGE	QTY
G	SIDE RAIL		2

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST


NORTHRIDGE DRIVE FULL BED

HARDWARE LISTS				
	ITEM DESCRIPTION	IMAGE	QTY	
1	Allen Wrench M4 x 55mm		1	
	JCBC Bolt M6 x P1.0 x 40mm	000	6	
2	Spring Washer M6 x 14mm			
	Flat Washer M6 x 19mm			
3	SCRBW M4 x 32mm	Ømmm.	10	
4	PHILIPS HEAD SCREWDRIVER (not included)		1	
	JCBB Bolt M8 x P1.25 x 20mm (pre assemble	:)		
5	Spring Washer M8 x 14mm (pre assemble) 000	8	
	Flat Washer M8x22mm (pre assemble)		
6	Leveller (pre assemble)	8	5	




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

Assembly Instructions:



STEP 2



Trundle - Attach the Side Rail (G) to the Headbord Legs (B). Tighten bolts using Allen Wrench (1) provided. Repeat step for Footboard (C).


Without Trundle - Attach the Side Rail (G) to the Headboard Legs (B) by removing the bolts and attach to the bottom 2 holes on the Legs (B) . Tighten bolts using Allen Wrench (1) provided. Repeat step for Footboard (C).

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST


Assembly Instructions:

STEP 3


Optional 1: For Reversible Underbed Storage Drawers and Trundle (NO SUPPORT LEGS REQUIRED)




Optional 2: For Full Bed



Optional 3: For Reversible Underbed Storage Drawers



Optional 4: For Trundle




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST


Assembly Instructions:

STEP 4

Optional 1 : For Reversible Underbed Storage Drawers & Trundle (NO SUPPORT LEGS REQUIRED)




Optional 2 : For Full Bed



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

Assembly Instructions:



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

Wooden Furniture Care

Protect Your Investment

The beauty of furnishing care is that it helps to protect your investment. Fine furniture is an important purchase. Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

Caring For Furniture

Caring for furniture is easy. Following a few simple guidelines will help extend the life of your furniture.

- *Always dust with a polish moistened cloth. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch the furniture surface if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics
- *Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood, causing damage.

The Enemies of Furniture

Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.

- *Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight, use sun screening drapes during intense sunlight hour, rotate furniture in place and in room arrangements.
- *Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses saucers under cups and flowerpots. If a spill occurs, immediately blot it gently without rubbing the surface.
- *Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective pads under hot dishes, utensils or cooking appliances.
- *Cyclic changes in temparature can damage furniture. I-lot blasts of air such as those found from central heating should be avoided because they cause extreme localized drying of the wood.

Tips for Better Dusting

- *Be sure in use the sauce type of polish consistently. Your furniture will appear cloudy or streaky if oil based and wax-based polished are interchanged.
- *Always use a fine furniture polish when dusting. Never dry dust, as it could cause microscopic scratches on your furniture surface. Remember to change dusting clothes frequently since a dirty cloth may scratch your furniture's surface.
- *Spray your furniture surface evenly, but not too generously. Wipe in a circular motion with a soft, clean cloth to clean and loosen the old polish.
- *Then, buff until completely dry for a beautiful shine and a smudge-resistant finish. For wood trim, spray polish on the cloth first, and then dust.