

SOUTH BEND

8-DRAWER CHESSER



RTG SKU#	STYLE#	COLOR	ITEM DESCRIPTION
34327507	275 - 181	Cherry	8-Drawer Chesser
34329501	295 - 181	White	8-Drawer Chesser

DO NOT USE SUBSTITUTE PARTS.
PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS
REPLACEMENT REQUEST

This product is manufactured by INRM for **ROOMS TO GO | KIDS™**

SOUTH BEND 8-DRAWER CHESSER

PART LIST			
NO.	ITEM DESCRIPTION	IMAGE	Q'TY
A	8-Drawer Chesser		1PC



HARDWARE LIST			
NO.	ITEM DESCRIPTION	IMAGE	Q'TY
1	Tipping Restraint		1 PC
Philips screwdriver is not included in hardware pack			

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling and keep these instructions for future reference.

Assembly Instructions:

STEP 1

Move the 8 Drawer Chesser into final position and use tipping restraint attach to wall.



DO NOT USE SUBSTITUTE PARTS.
PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by INRM for **ROOMS TO GO | KIDS™**