<section-header><section-header>

3407195P TWIN BED			
34671950	CARBON OPTIX	PAINTED BLACK	7195-370 TWIN STORAGE HEADBOARD
34771952	CARBON OPTIX	PAINTED BLACK	7195-380 TWIN PANEL FOOTBOARD W / SLATS
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS

3447195P TWIN BED WITH 1 REVERSIBLE UNDERBED STORAGE

34671950	CARBON OPTIX	PAINTED BLACK	7195-370 TWIN STORAGE HEADBOARD
34771952	CARBON OPTIX	PAINTED BLACK	7195-380 TWIN PANEL FOOTBOARD W / SLATS
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER

3457195P TWIN BED WITH 2 REVERSIBLE UNDERBED STORAGE

34671950	CARBON OPTIX	PAINTED BLACK	7195-370 TWIN STORAGE HEADBOARD
34771952	CARBON OPTIX	PAINTED BLACK	7195-380 TWIN PANEL FOOTBOARD W / SLATS
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by (SHHF) for ROOMS TO GO | KIDS Version #1 - 2024/07/26

CARBON OPTIX

TWIN BED

	HEADBOARD PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY	
А	HEADBOARD		1 PC	
В	E701 REMOTE CONTROL WITH LITHIUM BATTERY Type:CR2025	REC CONTRACTOR	1 PC	
	NOTE : "LOST YOUR REMOTE" CONTACT ROOMS TO GO CUSTOMER CARE TO PURCHASE A REPLACEMENT			


	FOOTBOARD PART LIST		
	ITEM DESCRIPTION	IMAGE	QTY
С	PANEL FOOTBOARD		1 PC
D	SLATS		5 PCS


	SIDE RAIL PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY	
E	STANDARD SIDE RAILS	Sector Contraction	2 PCS	


	OPTIONAL PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY	
F	REVERSIBLE UNDERBED STORAGE DRAWER		1 PC	

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by (SHHF) for ROOMS TO GO | KIDS Version #1 - 2024/07/26







Wooden Furniture Care

Protect Your Investment

The beauty of furnishing care is that it helps to protect your investment. Fine furniture is an important purchase. Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

Caring For Furniture

Caring for furniture is easy. Following a few simple guidelines will help extend the life of your furniture.

*Always dust with a polish moistened cloth. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch the furniture surface if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics

*Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood, causing damage.

The Enemies of Furniture

Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.

*Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight, use sun screening drapes during intense sunlight hour, rotate furniture in place and in room arrangements.

*Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses saucers under cups and flowerpots. If a spill occurs, immediately blot it gently without rubbing the surface.

*Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective pads under hot dishes, utensils or cooking appliances.

*Cyclic changes in temparature can damage furniture. I-lot blasts of air such as those found from central heating should be avoided because they cause extreme localized drying of the wood.

Tips for Better Dusting

*Be sure in use the sauce type of polish consistently. Your furniture will appear cloudy or streaky if oil based and wax-based polished are interchanged.

*Always use a fine furniture polish when dusting. Never dry dust, as it could cause microscopic scratches on your furniture surface. Remember to change dusting clothes frequently since a dirty cloth may scratch your furniture's surface.

*Spray your furniture surface evenly, but not too generously. Wipe in a circular motion with a soft, clean cloth to clean and loosen the old polish.

*Then, buff until completely dry for a beautiful shine and a smudge-resistant finish. For wood trim, spray polish on the cloth first, and then dust.