



RADIANCE

NARROW MIRROR W/LED LIGHT




SKU #	STYLE	COLOR	ITEM DESCRIPTION
34664400	644-4	WHITE	NARROW MIRROR W/LED LIGHT

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (GLOB) for **ROOMS TO GO®** | **KIDS**

RADIANCE


NARROW MIRROR W/LED LIGHT

MIRROR PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY
A	MIRROR SUPPORT BAR		2 PCS
B	MIRROR		1 PC
C	LIGHT STRIP ADAPTOR (Pre-assembled)		1 PC

HARDWARE LIST			
	ITEM DESCRIPTION	IMAGE	QTY
1	ALLEN KEY 4mmL		1 PC
PRE-ASSEMBLED HARDWARE FOR MIRROR SUPPORT BAR			
	ITEM DESCRIPTION	IMAGE	QTY
2	ALLEN BOLT Ø1/4" x 20 x 1 1/2"		8 PCS
3	SPRING WASHER Ø1/4"		8 PCS
4	FLAT WASHER Ø1/4"x 3/4"		8 PCS
5	THREAD WASHER Ø1/4"		8 PCS

HARDWARE PACK LOCATION

SKU #	STYLE	COLOR	ITEM DESCRIPTION
34664400	644-4	WHITE	NARROW MIRROR W/LED LIGHT




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (GLOB) for **ROOMS TO GO® | KIDS**


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly Instructions:

- STEP 1** Attach Support Bar (A) to back of Small Vanity Desk: Align the pre-assembled bolts on the Support Bars (A) with the pre-drilled holes on the Vanity Desk, tighten the pre-assembled bolts using Allen Key (1) provided.



- STEP 2** Attach Mirror (B) to Mirror Support Bar (A): Align the pre-assembled bolts on the Mirror Support Bars (A) with the pre-drilled holes on the Mirror (B), tighten the pre-assembled bolts using Allen Key (1) provided.




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (GLOB) for **ROOMS TO GO® | KIDS**

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly Instructions:

COMPLETED



Sold separately



4 WAY Touch Control with Dimming

1. Quick Touch = Color Change

Tap the dimming switch quickly to cycle through:

● 3000 K - Warm Glow

○ 4000 K - Natural Light

● 6500 K - Bright Daylight

● OFF

2. Press & Hold = Custom Dimming

Hold the switch for 5 seconds to activate smooth dimming. Adjust brightness to your perfect level

BY VANTAGE

CUSTOMER SERVICE :1-844-244-3810



Touch
switch
to turn
LED
lights
on & off

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (GLOB) for **ROOMS TO GO® | KIDS**

IMPORTANT SAFETY INSTRUCTIONS:

ELECTRICAL SAFETY INSTRUCTIONS

WARNING: DO not use extension cords or surge protectors unless they meet the following requirements:

- Cords must be 3rd party listed and rated for at least 15 amps at 120V *Third party listing symbol examples.*
- Use the minimum length extension cord possible.
- Check the cord for fraying, cuts, melted areas, or other damage.
- Never plug an extension cord into another extension cord.
- Household outlets should be GFCI protected otherwise a GFCI protected extension cord should be used.



Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK

12V/1.5A/18W

**Vantage City Group Limited
VAN-USAD-1812-F-DC**

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.



El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

12V/1.5A/18W

**Vantage City Group Limited
VAN-USAD-1812-F-DC**

Leer todas las instrucciones antes de usar este mobiliario.

PELIGRO - Para reducir el riesgo de descarga eléctrica:

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA: para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.