
CARBON OPTIX

FULL BED



3417195P FULL BED				
34871954	CARBON OPTIX	PAINTED BLACK	7195-470 FULL STORAGE HEADBOARD	
34971956	CARBON OPTIX	PAINTED BLACK	7195-480 FULL PANEL FOOTBOARD W / SLATS	
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS	

3467195P FULL BED WITH 1 REVERSIBLE UNDERBED STORAGE				
34871954 CARBON OPTIX PAINTED BLACK 7195-470 FULL STORAGE HEADBOARD				
34971956	CARBON OPTIX	PAINTED BLACK	7195-480 FULL PANEL FOOTBOARD W / SLATS	
35071959 CARBON OPTIX PAINTED BLACK 7195-350 TWIN / FULL SIDE		7195-350 TWIN / FULL SIDE RAILS		
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER	

3477195P FULL BED WITH 2 REVERSIBLE UNDERBED STORAGE				
34871954 CARBON OPTIX PAINTED BLACK 7195-470 FULL STORAGE HEADBOARD				
34971956	CARBON OPTIX	PAINTED BLACK	7195-480 FULL PANEL FOOTBOARD W / SLATS	
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS	
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER	
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER	

3487195P FULL BED WITH 1 REVERSIBLE UNDERBED STORAGE, AND 1 TWIN STORAGE TRUNDLE				
34871954	34871954 CARBON OPTIX PAINTED BLAC		7195-470 FULL STORAGE HEADBOARD	
34971956	CARBON OPTIX	PAINTED BLACK	7195-480 FULL PANEL FOOTBOARD W / SLATS	
35071959	CARBON OPTIX	PAINTED BLACK	7195-350 TWIN / FULL SIDE RAILS	
35171951	CARBON OPTIX	PAINTED BLACK	7195-001 REVERSIBLE UNDERBED STORAGE DRAWER	
35671951	CARBON OPTIX	PAINTED BLACK	7195-030 TWIN STORAGE TRUNDLE	

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

CARBON OPTIX

FULL BED

HEADBOARD PART LIST				
	ITEM DESCRIPTION	IMAGE	QTY	
A	HEADBOARD		1 PC	
В	E701 REMOTE CONTROL WITH LITHIUM BATTERY Type:CR2025		1 PC	
NOTE: "LOST YOUR REMOTE" CONTACT ROOMS TO GO CUSTOMER CARE TO PURCHASE A REPLACEMENT				

FOOTBOARD PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY
C	PANEL FOOTBOARD		1 PC
D	SLATS		5 PCS

	SIDE RAIL PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY	
E	STANDARD SIDE RAILS		2 PCS	


	OPTIONAL PART LIST			
	ITEM DESCRIPTION	IMAGE	QTY	
F	REVERSIBLE UNDERBED STORAGE DRAWER		1 PC	
G	TWIN STORAGE TRUNDLE		1 PC	

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

CARBON OPTIX

FULL BED


FOOTBOARD HARDWARE LIST				
	ITEM DESCRIPTION	IMAGE	QTY	
1	ALLEN WRENCH M4 x 60mm		1 PC	
2	CSK SCREW M4 x 32mm	Summing	10 PCS	
3	PHLIPS HEAD SCREWDRIVER (NOT PROVIDED)		1 PC	
4	JCBB BOLT M8 x P1.25 x 20mm (PRE ASSEMBLE)			
	SPRING WASHER M8 x 14mm (PRE ASSEMBLE)		8 PCS	
	FLAT WASHER M8 x 16mm (PRE ASSEMBLE)			



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly Instructions:



Storage - Attach the Side Rails (E) to the Headboard Legs (A). Tighten bolts using Allen Wrench (1) provided. Repeat step for Footboard (C).

Without Storage - Attach the Side Rails (E) to the Headboard Legs (A) by removing the bolts and attach to the bottom 2 holes on the Legs. Tighten bolts using Allen Wrench (1) provided. Repeat step for Footboard (C).




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by (SHHF) for ROOMS TO GO | KIDS Version #1 - 2024/07/26

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly Instructions:




DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by (SHHF) for ROOMS TO GO' \mid KIDS Version #1 - 2024/07/26

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling bed and keep these instructions for future reference.

Assembly Instructions:



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

Wooden Furniture Care

Protect Your Investment

The beauty of furnishing care is that it helps to protect your investment. Fine furniture is an important purchase. Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

Caring For Furniture

Caring for furniture is easy. Following a few simple guidelines will help extend the life of your furniture.

*Always dust with a polish moistened cloth. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch the furniture surface if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics

*Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood, causing damage.

The Enemies of Furniture

Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.

- *Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight, use sun screening drapes during intense sunlight hour, rotate furniture in place and in room arrangements.
- *Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses saucers under cups and flowerpots. If a spill occurs, immediately blot it gently without rubbing the surface.
- *Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective pads under hot dishes, utensils or cooking appliances.
- *Cyclic changes in temparature can damage furniture. I-lot blasts of air such as those found from central heating should be avoided because they cause extreme localized drying of the wood.

Tips for Better Dusting

- *Be sure in use the sauce type of polish consistently. Your furniture will appear cloudy or streaky if oil based and wax-based polished are interchanged.
- *Always use a fine furniture polish when dusting. Never dry dust, as it could cause microscopic scratches on your furniture surface. Remember to change dusting clothes frequently since a dirty cloth may scratch your furniture's surface.
- *Spray your furniture surface evenly, but not too generously. Wipe in a circular motion with a soft, clean cloth to clean and loosen the old polish.
- *Then, buff until completely dry for a beautiful shine and a smudge-resistant finish. For wood trim, spray polish on the cloth first, and then dust.