


CREEKSID 3.0

CASTER DESK




SKU#	STYLE	COLOR	ITEM DESCRIPTION
34732520	325-DKSN	CHESTNUT	CASTER DESK
34732532	325-DKSC	CHARCOAL	CASTER DESK


DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (JSFC) for **ROOMS TO GO® | KIDS**

CREEKSIDE 3.0

CASTER DESK


CASTER DESK PART LIST		
ITEM DESCRIPTION	IMAGE	QTY
A CASTER DESK		1 PC

CASTER DESK PRE-ASSEMBLED HARDWARE LIST		
ITEM DESCRIPTION	IMAGE	QTY
1 CASTER		6 PCS

HARDWARE PACK LOCATION

STEP 1

To replace the caster, pull out the caster by hand, then insert the new caster as shown.



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST.

This product is manufactured by (JSFC) for **ROOMS TO GO® | KIDS**