







EMILIE ROSE

REVERSIBLE UNDERBED STORAGE DRAWERS



RTG SKU#	STYLE#	COLOR	ITEM DESCRIPTION
35271890	7189-001	WIREBRUSH GRAY	REVERSIBLE UNDERBED STORAGE DRAWERS


REVERSIBLE UNDERBED STORAGE DRAWERS - PARTS LIST			
NO.	ITEM DESCRIPTION	IMAGE	Q'TY
A	DRAWER UNIT		1PC
B	TOP PANEL		1PC
C	BOTTOM PANEL		1PC
D	BACK PANEL		1PC
E	SIDE PANEL		1PC

DO NOT USE SUBSTITUTE PARTS.
PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS
REPLACEMENT REQUEST

This product is manufactured by YUYU for **ROOMS TO GO® | KIDS**


EMILIE ROSE

REVERSIBLE UNDERBED STORAGE DRAWERS

REVERSIBLE UNDERBED STORAGE DRAWERS - HARDWARE LIST			
NO.	ITEM DESCRIPTION	IMAGE	Q'TY
1	Allen Wrench M4 x 74 x 30mm		1PC


Hardware pack location

RTG SKU#	STYLE#	COLOR	ITEM DESCRIPTION
35271890	7189-001	WIREBRUSH GRAY	REVERSIBLE UNDERBED STORAGE DRAWERS



PARTS DETAIL

NOTE : Cubby can be attached to either side of the Drawer Unit.
Before proceeding with assembly, decide which side you would like the cubby to be.
Recommend to have the open section at the head of the bed so the drawer is not blocked by the nightstand.



DO NOT USE SUBSTITUTE PARTS.
PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by YUYU for **ROOMS TO GO® | KIDS**


EMILIE ROSE

REVERSIBLE UNDERBED STORAGE DRAWERS


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below. Read all instructions before assembling and keep these instructions for future reference.

Assembly Instructions:



STEP 1



STEP 2



STEP 3



DO NOT USE SUBSTITUTE PARTS.

PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

This product is manufactured by YUYU for **ROOMS TO GO® | KIDS**

Wooden Furniture Care

Protect Your Investment

The beauty of furnishing care is that it helps to protect your investment. Fine furniture is an important purchase. Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

Caring For Furniture

Caring for furniture is easy. Following a few simple guidelines will help extend the life of your furniture.

*Always dust with a polish moistened cloth. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch the furniture surface if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics

*Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood, causing damage.

The Enemies of Furniture

Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.

*Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight, use sun screening drapes during intense sunlight hour, rotate furniture in place and in room arrangements.

*Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses saucers under cups and flowerpots. If a spill occurs, immediately blot it gently without rubbing the surface.

*Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective pads under hot dishes, utensils or cooking appliances.

*Cyclic changes in temperature can damage furniture. Hot blasts of air such as those found from central heating should be avoided because they cause extreme localized drying of the wood.

Tips for Better Dusting

*Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based and wax-based polishes are interchanged.

*Always use a fine furniture polish when dusting. Never dry dust, as it could cause microscopic scratches on your furniture surface. Remember to change dusting clothes frequently since a dirty cloth may scratch your furniture's surface.

*Spray your furniture surface evenly, but not too generously. Wipe in a circular motion with a soft, clean cloth to clean and loosen the old polish.

*Then, buff until completely dry for a beautiful shine and a smudge-resistant finish. For wood trim, spray polish on the cloth first, and then dust.